

Steenks Service B.V. T+31(0) 174 510 266 2678 LH De Lier The Netherlands

Jan van de Laarweg 1 F +31(0) 174 518 326 E info@steenks-service.com W www.steenks-service.fr

IBAN NL81 RABO 03362.33.868 **BIC RABO NL 2U** CoC No. Naaldwijk 27290116 VAT NL816975474B01



Hygiene station

Article code DIV0000101

Selling type New

Brand Steenks Service

Type

Length 156 cm Width 104 cm Height 107 cm



Min. height Max. height cm

✓ one-person passage through a tourniquet ✓ aluminum frame coated in standard RAL color

✓ stainless steel foot support, railing and ✓ with plastic walk-over-surface in foottourniquet disinfectiontray

✓ walk-over-surface automatically fills by means ✓ foot fluid-level is controlled automatically of the buffer tank

✓ to unlock the tourniquet you have to push the ✓ installation works on 230 volts.

buttons in the disinfection-tray simultaneously

More information about Hygiene station

HS-code: 73089098

Steenks Service advises to use as a disinfectant for the hygiene station:

The formulated broad spectrum efficacy of disinfectant Virkon can help to prevent the entry of pathogens and combat. In independent tests disinfectant Virkon S proved effective against various viruses, bacteria and fungi. At low temperatures, and hard water with organic pollution.

This disinfectant is a water-soluble powder, and can be used with a mixing ratio of 1: 1200.



